

## Packet Tracer – Subnet an IPv4 Network

### Addressing Table

| Device          | Interface | IP Address      | Subnet Mask     | Default Gateway |
|-----------------|-----------|-----------------|-----------------|-----------------|
| CustomerRouter  | G0/0      | 192.168.0.1     | 255.255.255.192 | N/A             |
|                 | G0/1      | 192.168.0.65    | 255.255.255.192 |                 |
|                 | S0/1/0    | 209.165.201.2   | 255.255.255.252 |                 |
| LAN-A Switch    | VLAN1     | 192.168.0.2     | 255.255.255.192 | 192.168.0.1     |
| LAN-B Switch    | VLAN1     | 192.168.0.66    | 255.255.255.192 | 192.168.0.65    |
| PC-A            | NIC       | 192.168.0.62    | 255.255.255.192 | 192.168.0.1     |
| PC-B            | NIC       | 192.168.0.126   | 255.255.255.192 | 192.168.0.65    |
| ISPRouter       | G0/0      | 209.165.200.225 | 255.255.255.224 | N/A             |
|                 | S0/1/0    | 209.165.201.1   | 255.255.255.252 |                 |
| ISPSwitch       | VLAN1     | 209.165.200.226 | 255.255.255.224 | 209.165.200.225 |
| ISP Workstation | NIC       | 209.165.200.235 | 255.255.255.224 | 209.165.200.225 |
| ISP Server      | NIC       | 209.165.200.240 | 255.255.255.224 | 209.165.200.225 |

### Objectives

**Part 1: Design an IPv4 Network Subnetting Scheme**

**Part 2: Configure the Devices**

**Part 3: Test and Troubleshoot the Network**

### Background / Scenario

In this activity, you will subnet the Customer network into multiple subnets. The subnet scheme should be based on the number of host computers required in each subnet, as well as other network considerations, like future network host expansion.

After you have created a subnetting scheme and completed the table by filling in the missing host and interface IP addresses, you will configure the host PCs, switches and router interfaces.

After the network devices and host PCs have been configured, you will use the **ping** command to test for network connectivity.

## Instructions

### Part 1: Subnet the Assigned Network

#### Step 1: Create a subnetting scheme that meets the required number of subnets and required number of host addresses.

In this scenario, you are a network technician assigned to install a new network for a customer. You must create multiple subnets out of the 192.168.0.0/24 network address space to meet the following requirements:

- The first subnet is the LAN-A network. You need a minimum of 50 host IP addresses.
- The second subnet is the LAN-B network. You need a minimum of 40 host IP addresses.
- You also need at least two additional unused subnets for future network expansion.

**Note:** Variable length subnet masks will not be used. All of the device subnet masks should be the same length.

- Answer the following questions to help create a subnetting scheme that meets the stated network requirements:

How many host addresses are needed in the largest required subnet?

**At least 50 host addresses.**

What is the minimum number of subnets required?

**4 subnets including 2 for future network expansion.**

The network that you are tasked to subnet is 192.168.0.0/24. What is the /24 subnet mask in binary?

**11111111.11111111.11111111.00000000**

- The subnet mask is made up of two portions, the network portion, and the host portion. This is represented in the binary by the ones and the zeros in the subnet mask.

In the network mask, what do the ones represent?

**The network portion**

In the network mask, what do the zeros represent?

**The host portion**

- To subnet a network, bits from the host portion of the original network mask are changed into subnet bits. The number of subnet bits defines the number of subnets.

Given each of the possible subnet masks depicted in the following binary format, how many subnets and how many hosts are created in each example?

**Hint:** Remember that the number of host bits (to the power of 2) defines the number of hosts per subnet (minus 2), and the number of subnet bits (to the power of two) defines the number of subnets. The subnet bits (shown in bold) are the bits that have been borrowed beyond the original network mask of /24. The /24 is the prefix notation and corresponds to a dotted decimal mask of 255.255.255.0.

- 1) (/25) 11111111.11111111.11111111.**10000000**

Dotted decimal subnet mask equivalent:

**255.255.255.128**

Number of subnets? Number of hosts?

**Subnets: 2**

**Hosts: 126 each**

- 2) (/26) 11111111.11111111.11111111.11000000

Dotted decimal subnet mask equivalent:

**255.255.255.192**

Number of subnets? Number of hosts?

**Subnets: 4, Hosts: 62**

- 3) (/27) 11111111.11111111.11111111.11100000

Dotted decimal subnet mask equivalent:

**255.255.255.224**

Number of subnets? Number of hosts?

**Subnets: 8, Hosts: 30**

- 4) (/28) 11111111.11111111.11111111.11110000

Dotted decimal subnet mask equivalent:

**255.255.255.240**

Number of subnets? Number of hosts?

**Subnets: 16, Hosts: 14**

- 5) (/29) 11111111.11111111.11111111.11111000

Dotted decimal subnet mask equivalent:

**255.255.255.248**

Number of subnets? Number of hosts?

**Subnets: 32, Hosts: 6**

- 6) (/30) 11111111.11111111.11111111.11111100

Dotted decimal subnet mask equivalent:

**255.255.255.252**

Number of subnets? Number of hosts?

**Subnets: 64, Hosts: 2**

Considering your answers above, which subnet masks meet the required number of minimum host addresses?

**/25 or /26**

Considering your answers above, which subnet masks meets the minimum number of subnets required?

**/25, /26, /27, /28, /29**

Considering your answers above, which subnet mask meets both the required minimum number of hosts and the minimum number of subnets required?

**/26. /25 has enough hosts, but only 2 subnets, so we can't use /25**

When you have determined which subnet mask meets all of the stated network requirements, derive each of the subnets. List the subnets from first to last in the table. Remember that the first subnet is 192.168.0.0 with the chosen subnet mask.

| Subnet Address | Prefix | Subnet Mask     |
|----------------|--------|-----------------|
| 192.168.0.0    | /26    | 255.255.255.192 |
| 192.168.0.64   | /26    | 255.255.255.192 |
| 192.168.0.128  | /26    | 255.255.255.192 |
| 192.168.0.192  | /26    | 255.255.255.192 |

## Step 2: Fill in the missing IP addresses in the Addressing Table

Assign IP addresses based on the following criteria: Use the ISP Network settings as an example.

- a. Assign the first subnet to LAN-A.
  - 1) Use the first host address for the CustomerRouter interface connected to LAN-A switch.
  - 2) Use the second host address for the LAN-A switch. Make sure to assign a default gateway address for the switch.
  - 3) Use the last host address for PC-A. Make sure to assign a default gateway address for the PC.
- b. Assign the second subnet to LAN-B.
  - 1) Use the first host address for the CustomerRouter interface connected to LAN-B switch.
  - 2) Use the second host address for the LAN-B switch. Make sure to assign a default gateway address for the switch.
  - 3) Use the last host address for PC-B. Make sure to assign a default gateway address for the PC.

## Part 2: Configure the Devices

Configure basic settings on the PCs, switches, and router. Refer to the Addressing Table for device names and address information.

### Step 1: Configure CustomerRouter.

- a. Set the enable secret password on CustomerRouter to **Class123**
- b. Set the console login password to **Cisco123**.
- c. Configure **CustomerRouter** as the hostname for the router.
- d. Configure the G0/0 and G0/1 interfaces with IP addresses and subnet masks, and then enable them.
- e. Save the running configuration to the startup configuration file.

### Step 2: Configure the two customer LAN switches.

Configure the IP addresses on interface VLAN 1 on the two customer LAN switches. Make sure to configure the correct default gateway on each switch.

### Step 3: Configure the PC interfaces.

Configure the IP address, subnet mask, and default gateway settings on **PC-A** and **PC-B**.

## Part 3: Test and Troubleshoot the Network

In Part 3, you will use the **ping** command to test network connectivity.

- a. Determine if PC-A can communicate with its default gateway. Do you get a reply?

Yes i got 100%

b. Determine if PC-B can communicate with its default gateway. Do you get a reply?

Yes i got 100%

c. Determine if PC-A can communicate with PC-B. Do you get a reply?

Yes, both PC-A and PC-B can send pings to each other.

If you answered “no” to any of the preceding questions, then you should go back and check your IP address and subnet mask configurations, and ensure that the default gateways have been correctly configured on PC-A and PC-B.